


Cable Assembly Procedure

Step 1 Trim cable to dimensions shown point center conductor. (.315 dimensions for jacketed cables only).



1

В

А

REV

С

SHEET 1

PLATING OPT.

OF 1

Step 2

В

Α

Slide contact onto center conductor. Butt against dielectric. Heat contact and reflow solder. Use solder paste if necessary. Clean.



ECN 13788

ECN7715

ECN 3489

DESCRIPTION

В

А

۶FV

6/17/20

12/8/4

7/16/96

DATE

JEM

JEM

ΗN

BY

2

Slide cable into body and solder to outer cable jacket. Clean.

UNLESS OTHERWISE SPECIFIED, PHOENIX WORKMANSHIP STANDARDS APPL' DIMENSIONS IN INCHES OR (METRIC)

DO NOT SCALE PRINTS

THE INFORMATION AND DESIGNS

THER PURPOSE WITHOUT THE XPRESS WRITTEN CONSENT OF THE HOENIX COMPANY OF CHICAGO

OSED IN THIS DOCUMENT ARE IDENTIAL AND/OR RIFLARY TO THE PHOENIX PANY OF CHICAGO INC. AND NOT BE USED FOR IFACTURING, REPRODUCED, OSED TO OTHERS OR FOR ANY BUIDEOSE WITCHIT THE

32,

ENGINEER


APPROVED JEM

ĴSV

42

TOLERANCES ARE:

FRACTIONS: ± 1/64 DECIMALS: .XX ± .01 .XXX ± .003 ANGLES: ± 1/2'



FSCM DWG NO

ESR ±

28-1020-1410

1

58167

SIZE

Α

SCALE

7/16/96

7/16/96